

Pressed Tin Panels Installation Instructions

General Application

Recommended Tools & Supplies needed.

Hammer – 25mm x 1.6mm or 1.4mm Wall Board Nails – Tin Snips – Chalk Line – Tape Measure Gloves – Thin cutting disc for aluminium products. (We do sell these directly)

Caution should be used at all time as metal edges are Very Sharp.

NOTE: Stickers on back of sheeting are a guide showing which direction they have been ran through press. These stickers are to be used as a guide during installing. When erecting large areas they should all run in one direction if possible.

Step 1 Using sawhorses and heavy planking, erect scaffolding in the room to work from.

Step 2 To begin if the ceiling is level, we recommend fix 6or 9mm MDF to the whole ceiling. This makes it not only easier but lowers the ceiling height less then 3/8” or 1/2” which is fine.

Step 3 We recommend that you lay all your ceiling and cornice items out on the floor before affixing any in place. This familiarise yourself on how the overlaps works. This is just to insure that you are sure of exactly how the product all goes together which will be critical later in the project.

Step4 Installing of the Metal Cornice is the first thing to be done. Mounting strips are to be installed first. (Mounting stirps are a product of Pressed Tin Panels only and a be used with our products only) This can be installed with a small nail, tack or screw, the lip is to face out. Small dab of liquid nails just above the lip. This will prevent it from moving at a later date. Metal Cornices then slip into the strip. We do recommend that a wooden batten backing is put attached from the ceiling out for a guide. This just insures that the cornice runs even the whole length of the room. The cornice can then be affixed to the ceiling using small nails, tacks etc

Step 5 Mitring of Metal Cornice the left hand side should run into the corner wall left unmitred. Then the right hand side should run along and using a scribe or compass to transfer the profile of the left hand cornice onto the right hand cornice. Trim this down using a pair of tin snips. This process might need to be done a couple of times to get a neat fit.

Step 6 Snap a chalk line on the centre of the plywood in the centre of the room. This will equalise the centre of the pattern the outer parallel walls. Making sure that sheets overlap towards the door, under lapping sheets moving away from the door. This is done so the seam faces the back. Align the edge of the sheet with the chalk line and attach the sheet using nails at 150mm approx intervals where they overlap and 300mm approx intervals down the centre. All nailing points differ with each individual pattern this is to be accessed by the installer.

Step 7 Ceiling panels can now be erected starting from the centre of the room working your way to the edges. We suggest that you affix all ceiling panels in the centre of the panel first. This avoids any sagging or buckling of the product.

Step 8 All our aluminium products are acid etched to prepare the surface for painting. You need to wipe all finger prints and marks from the panels prior to applying an under coat then painting. It is recommended that you use Acrylic or Oil based paints.

All instructions are given as a guide only. We hold no responsibility for the incorrect installation or use of our products. We do not recommend mixing patterns which look similar with other pressed metal products on the market. This is because there are variances in the sizing of each product. If you have any questions please feel free to contact the store of purchase or Pressed Tin Panels directly.

SNOWFLAKES INFO: Please use sticker indicating overlap this is extremely important.

PRODUCT INFORMATION

CHEMICAL PROCESS – All our products are treated with a chemical etch process which is Clear, colourless, concentrated liquid acid detergent which has been formulated especially for Cleaning and brightening aluminium surfaces prior to painting.

USER BENEFITS –

- Simultaneous removal of light oil and grease deposits along with etching of Aluminium.
- Produces a white, bright finish on aluminium sheets
- Simultaneous cleaning and etching of aluminium prior to painting or powder coating
- Our Galvanised products are not treated with this process unless requested
- The etching is a Under Pre treatment prior to painting no primer is necessary unless You specifically wish to do this process. If so a light coating is all is needed.
- If you have any questions on this please contact us or consult your local paint specialist.
- The only preparation we recommend prior to painting is to wipe with a clean rag to **Remove all finger marks and apply a light coat of primer.**

If you have any further questions please don't hesitate to contact us directly or your store of purchase.

Pressed Tin Panels 02 63321738 or 0419 414 267

PRODUCT SUPPLIED BY: