

## PRESSED TIN PANELS CORNICE INSTULATION INSTRUCTIONS



1/Shows the Cornice Mounting Strip which is To be installed first. This can be install with a Small nail, tack or screw. Lip is to face out.



2/ Shows the cornice slipping into the Mounting strip straight over an existing Gyprock Cornice. There is no need to remove old Cornices unless The old is larger than the new.



3/Shows the Cornice in place, which you can Then affix along the top edge into your ceiling with nails, tacks etc



4/ This picture shows the sheeting then going over the top edge and butting up ready for affixing in place. Sheeting must be started from the centre of the room, not the edge.  
**NOTE:** In some cases that a batten will be needed to be fitted. Place batten width from the wall, to The back of the cornice. This is to push cornice against to prevent any distortion which might occur.

## INSTRUCTIONS FOR MITRING CORNICES



1/ Shows sliding the cornice into the mitre box



2/ Shows scribing in nominated position. Scriber to be held flat to end plate.



3/ Move along in Mitre Box approx 100mm Clamp to hold in place prior to cutting, cut 5mm to the outer side of scribed line.



4/ Move back in mitre box until the scribed line is In line with the mitre box end plate. Now clamp And hold, remove the 5mm with cut off disc running On mitre box end plate. (Cutting disc needs to be Thin wall 1.2mm, lubricate cutting disc by swiping into block of bees wax or candle was.



5/Deburring of any sharp edges left on Cornice with metal file



6/Picture shows Left hand Cornice still Left square for installing. Right Hand Cornice Mitred Corner.



7/ Picture shows both Cornices coming together, Just as they will be when installed.



8/Shows example of finished Mitred Cornice.



9/Shows putting in Cornice in the Mounting strips overlapping each cornice.



10/ Shows the tools needed to complete the job Mitre box, Small Grinder, 1mm Aluminium Grinding Wheel, Clamp & Bees Wax for lubricating the disc.

**NOTE:** All photos shown are internal Angles. All instructions are given as a guide only. Pressed Tin Panels will not be held responsible for the misuse of instructions. Pictures above Are of the Grate and Egg & Grape Cornice. Products are only recommended to affix to Ply wood Or battens. All instructions are designed for our Products only. If you have any questions please Contact us on 02 6332 1738 or 0419 414 267.

For all Cornice profile please refer to our web site [www.pressedtinpanels.com](http://www.pressedtinpanels.com)

**SUPPLIER:**