

GENERAL INSTALLATION INSTRUCTIONS FOR WET AREAS

Rendered Wall: Painted

If painted spots the size of 20 cent coin every 300mm² must be scoured back to render.

Rendered Wall: Unpainted

If unpainted must be clean and firm, not powdery.

General Application

Maxi Bond or Liquid nails are suitable at one tube per sheet. Apply as “Walnuts” (i.e. approximately 30 -35mm dobs) up to 10mm thick every 300mm² placed on sheet or wall-sheet pressed to wall – rub hands firmly over sheet. Then pull sheet back off wall at an angle of 20- 25 degrees and wait 5 minutes for adhesive to go off. Then push sheet back against wall again, rubbing firmly – check every ½ hour for the next 2 hours and if necessary re-press in selected spots. If a “spot” is not flat drill 1/8” hole then put in 1/8” pop rivet to secure.

When putting 2nd sheet on the edge that overlaps should have a thin bead of glue edge between sheets, push together and fix with pop rivets at 450mm centres then with a wet rag wipe off excess glue.

Try not to join two sheets in a corner. If access to a sheetmetal shop – fold a sheet at a right angle and place in 1st corner other corners – again fold sheets as required. Alternatively – sheet can be ‘scored’ on the reverse side of the panel then placed over a straight edge and manually fold along the scored section (see picture in ‘Wall Panel installation Sheet’).

At top of panels approx 1800mm height, refer to Borders to use as capping to finish off.

When fixing 1st sheet put plum line and work out sheets, just don’t start in one corner. If unclear or further information required please contact Pressed Tin Panels for advice. Please note this is a general installation guideline for application to wet area scenarios only and Pressed Tin Panels holds no responsibility for incorrect or inappropriate installation of product or associated materials.

INSTALLING OF LILY & POSY SHEETING AS SHOWN.

The Lily & Posy pattern must be staggered when being installed up to 1800mm in Height on the 900mm panels only. This only means that the first 150mm will be lost. The reason the pattern needs to be staggered as the pattern repeats itself every 600mm and we are producing it in 900mm high sheets. These instructions do not apply to the 600mm high Posy Panel. Any questions please ring our office and we can go through the process with you. Or ring **02 63321738**.

